



Gowin USB 1.1 SoftPHY IP

User Guide

IPUG759-1.1E, 04/09/2021

Copyright©2021 Guangdong Gowin Semiconductor Corporation. All Rights Reserved.

No part of this document may be reproduced or transmitted in any form or by any denotes, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of GOWINSEMI.

Disclaimer

GOWINSEMI®, LittleBee®, Arora, and the GOWINSEMI logos are trademarks of GOWINSEMI and are registered in China, the U.S. Patent and Trademark Office, and other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders, as described at www.gowinsemi.com. GOWINSEMI assumes no liability and provides no warranty (either expressed or implied) and is not responsible for any damage incurred to your hardware, software, data, or property resulting from usage of the materials or intellectual property except as outlined in the GOWINSEMI Terms and Conditions of Sale. All information in this document should be treated as preliminary. GOWINSEMI may make changes to this document at any time without prior notice. Anyone relying on this documentation should contact GOWINSEMI for the current documentation and errata.

Revision History

Date	Version	Description
01/06/2021	1.0E	Initial version published.
04/09/2021	1.1E	Chapter 3 Functional Description modified.

Contents

Contents	i
List of Figures	ii
List of Tables	iii
1 About This Guide	1
1.1 Purpose	1
1.2 Related Documents	1
1.3 Terminology and Abbreviations.....	1
1.4 Support and Feedback	2
2 Introduction	3
2.1 Overview.....	3
2.2 Features.....	3
3 Functional Description	4
3.1 USB 1.1 SoftPHY.....	4
4 Signal Description	7
4.1 Signal Description.....	7
4.2 Parameter Configuration Option.....	8
5 Interface Configuration	9

List of Figures

Figure 3-1 SoftPHY Block Diagram	4
Figure 3-2 USB Master Device Interface Implementation	5
Figure 3-3 USB Slave Device Interface Implementation	5
Figure 3-4 USB Slave Device Interface Implementation	6
Figure 5-1 IP Core Generator	9
Figure 5-2 Open USB 1.1 SoftPHY IP Core	10
Figure 5-3 USB 1.1 SoftPHY IP Configuration Interface	10

List of Tables

Table 1-1 Terminology and Abbreviations	2
Table 4-1 Signals Description	7
Table 4-2 Configuration Option	8

1 About This Guide

1.1 Purpose

The purpose of Gowin USB 1.1 SoftPHY User Guide is to help you learn the features and usage of Gowin USB 1.1 by providing an overview of the signal description, functional description and interface configuration.

1.2 Related Documents

The latest user guides are available on the GOWINSEMI Website. You can find the related documents at www.gowinsemi.com:

1. [DS100](#), GW1N series of FPGA Products Data Sheet
2. [DS117](#), GW1NR series of FPGA Products Data Sheet
3. [DS891](#), GW1NRF series of FPGA Products Data Sheet
4. [DS821](#), GW1NS series of FPGA Products Data Sheet
5. [DS871](#), GW1NSE series of FPGA Products Data Sheet
6. [DS881](#), GW1NSER series of FPGA Products Data Sheet
7. [DS861](#), GW1NSR series of FPGA Products Data Sheet
8. [DS102](#), GW2A series of FPGA Products Data Sheet
9. [DS226](#), GW2AR series of FPGA Products Data Sheet
10. [SUG100](#), Gowin Software User Guide

1.3 Terminology and Abbreviations

The terminology and abbreviations used in this manual are as shown in Table 1-1.

Table 1-1 Terminology and Abbreviations

Terminology and Abbreviations	Meaning
IP	Intellectual Property
USB	General Serial Bus
UTMI	USB 2.0 Transceiver Macrocell Interface
HS	High Speed
FS	Full Speed
LS	Low Speed

1.4 Support and Feedback

Gowin Semiconductor provides customers with comprehensive technical support. If you have any questions, comments, or suggestions, please feel free to contact us directly by the following ways.

Website: www.gowinsemi.com

E-mail: support@gowinsemi.com

2 Introduction

2.1 Overview

Gowin USB 1.1 SoftPHY IP is a USB physical layer transceiver that can support data reception and transmission at full speed (12Mbps) or low speed (1.5Mbps).

2.2 Features

The features of USB 1.1 SoftPHY IP include:


- Supports Full Speed Mode (12Mbps) and Low Speed Mode (1.5Mbps);
- Supports data serial and parallel conversion;
- Supports bit stuffing and extraction;
- Supports NRZI encoding and decoding;
- Supports UTMI interface.

3 Functional Description

3.1 USB 1.1 SoftPHY

In the RX direction, after USB serial data goes through the modules including: CDR, NRZI decoding, bit extraction, data shifting, the realized USB RX data is received, and the received data goes through the UTMI interface to send to the upper module. In the TX direction, after receiving the transmit data, the USB serial data goes through the modules including: data shifting, bit filling, NRZI encoding to generate the serial TX data stream.


Figure 3-1 SoftPHY Block Diagram



USB 1.1 SoftPHY supports Full Speed Mode (12Mbps) and Low Speed


Mode (1.5Mbps); When USB 1.1 SoftPHY is used as the master device, a 15K pull-down resistor needs to be connected to Data+ and Data-.

Figure 3-2 USB Master Device Interface Implementation




When USB 1.1 SoftPHY is used as the slave device in full speed, a 1.5K pull-down resistor needs to be connected to Data+.

Figure 3-3 USB Slave Device Interface Implementation



When USB 1.1 SoftPHY is used as the slave device in low speed, a 1.5K pull-down resistor needs to be connected to Data-.

Figure 3-4 USB Slave Device Interface Implementation



4 Signal Description

4.1 Signal Description

A description of signals is as shown in Table 4-1.

Table 4-1 Signals Description

No.	Signal Name	I/O	Data Width	Description	Remarks
1	clk_i	I	1	Input clock signal (24MHz/48MHz/60MHz)	
2	rst_i	I	1	Asynchronous reset signal resets the state machine inside of PHY.	
3	utmi_data_out_i	I	8	Data input, 8 bit parallel send data bus.	
4	utmi_txvalid_i	I	1	Transmit data is valid, active-high.	
5	utmi_opmode_i	I	2	Operation mode selection signal: <ul style="list-style-type: none"> ● 2'b00: Normal ● 2'b01: No driver ● 2'b10: Disable bit stuffing and NRZI encoding ● 2'b11: Operation of not automatically generating start and end signals 	
6	utmi_xcvrselect_i	I	2	Transmit mode selection signal: <ul style="list-style-type: none"> ● 2'b00: HS transmission (Not supported) ● 2'b01: FS transmission ● 2'b10: LS transmission ● 2'b11: Reserved 	
7	utmi_termselect_i	I	1	Termination selection: <ul style="list-style-type: none"> ● 1' b0: HS termination enable (Not supported) ● 1' b1: FS/LS termination enable 	

No.	Signal Name	I/O	Data Width	Description	Remarks
8	utmi_data_in_o	O	8	Data Output, 8 bits parallel data receive bus.	
9	utmi_txready_o	O	1	Transmit data ready completed signal, indicating that PHY can receive this data.	
10	utmi_rxactive_o	O	1	Receive data activation indicates that the receive state machines detects the SYNC signal and starts receiving data.	
11	utmi_rxvalid_o	O	1	Receive data is valid, active-high.	
12	utmi_rxerror_o	O	1	Receive data error, active-high indicates receive error.	
13	utmi_linestate_o	O	2	Line status of receive: DM DP <ul style="list-style-type: none"> ● 2'b00: SE0 ● 2'b01: "J" ● 2'b10: "K" ● 2'b11: SE1 	
14	usb_dp_io	I/O	1	USB data signal Data+	
15	usb_dn_io	I/O	1	USB data signal Data-	

4.2 Parameter Configuration Option

Gowin USB 1.1 SoftPHY IP parameter configuration is shown in Table 4-2.

Table 4-2 Configuration Option

Option	Description
Clock Frequency	Working clock frequency setting includes 24MHz, 48MHz and 60MHz.


5 Interface Configuration

Select “Tools” in the Gowin software interface, and it can start the IP Core Generator tool, call and configure USB 1.1 SoftPHY.

1. Open IP Core Generator

After creating the project, you can click the “Tools” tab in the upper left, select and open the IP Core Generator via the drop-down list, as shown in Figure 5-1.


Figure 5-1 IP Core Generator



2. Open USB 1.1 SoftPHY IP Core

Select “Soft IP Core > Interface and Interconnect > USB 1.1 IP”, as shown in Figure 5-2. Double click to open the configuration interface.

Figure 5-2 Open USB 1.1 SoftPHY IP Core



3. USB 1.1 SoftPHY IP Core Configuration Interface

Figure 5-3 shows the USB 1.1 SoftPHY IP core configuration interface. The interface diagram is on the left. Options are on the right.

- You can configure the file name in File Name;
- You can configure the top module name in Module Name;
- You can configure the speed mode, the power supply mode, the endpoint transmission type, etc. in Options.

Figure 5-3 USB 1.1 SoftPHY IP Configuration Interface

