



# Gowin\_EMPU\_M3 Serial Debugging **Reference Manual**

IPUG920-1.1E, 07/16/2021

**Copyright © 2021 Guangdong Gowin Semiconductor Corporation. All Rights Reserved.**

**GOWIN**, Gowin and GOWINSEMI are trademarks of Guangdong Gowin Semiconductor Corporation and are registered in China, the U.S. Patent and Trademark Office, and other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders. No part of this document may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of GOWINSEMI.

### **Disclaimer**

GOWINSEMI assumes no liability and provides no warranty (either expressed or implied) and is not responsible for any damage incurred to your hardware, software, data, or property resulting from usage of the materials or intellectual property except as outlined in the GOWINSEMI Terms and Conditions of Sale. All information in this document should be treated as preliminary. GOWINSEMI may make changes to this document at any time without prior notice. Anyone relying on this documentation should contact GOWINSEMI for the current documentation and errata.

## Revision History

Date	Version	Description
04/03/2020	1.0E	Initial version published.
07/16/2021	1.1E	FPGA and MCU software version updated.

# Contents

<b>Contents .....</b>	<b>i</b>
<b>List of Figures .....</b>	<b>ii</b>
<b>List of Tables .....</b>	<b>iii</b>
<b>1 Overview .....</b>	<b>1</b>
<b>2 Hardware Resource .....</b>	<b>2</b>
<b>3 Software Resource .....</b>	<b>3</b>
<b>4 Reference Design .....</b>	<b>4</b>
<b>5 Debugging Flow .....</b>	<b>5</b>
5.1 Hardware Design .....	5
5.1.1 Hardware Design .....	5
5.1.2 Physical Constraint .....	5
5.2 Software Programming .....	5
5.3 Board Level Connection .....	5
5.4 Serial Debugging Assistant .....	6

# List of Figures

Figure 5-1 Serial Debugging Assistant ..... 6

# List of Tables

Table 5-1 UART0/1 Port Constraints in Reference Design ..... 5

# 1 Overview

Gowin\_EMPU\_M3 supports serial port debugging. The master computer communicates with the slave computer by serial ports. Serial debugging assistant software is used to trace the debugging information on the PC side.

# 2 Hardware Resource

- Development board: DK-START-GW2A55 V1.3  
GW2A-LV55PG484C8/I7
- USB to serial port interface board
- PC



# 3 Software Resource

- Gowin\_V1.9.8 Beta and above
- ARM Keil MDK (V5.26 and above) and GOWIN MCU Designer (V1.1 and above)
- Serial Debugging Assistant Software

# 4 Reference Design

Gowin\_EMPU\_M3 provides serial port debugging reference design in ARM Keil MDK V5.26 and above and GOWIN MCU Designer V1.1 and above.

- Gowin\_EMPU\_M3\ref\_design\MCU\_RefDesign\Keil\_RefDesign\peripherals\_app
- Gowin\_EMPU\_M3\ref\_design\MCU\_RefDesign\GMD\_RefDesign\sm3\_peripherals\_app

# 5 Debugging Flow

## 5.1 Hardware Design

### 5.1.1 Hardware Design

1. Select Gowin\_EMPU\_M3 in Gowin IP Core Generator;
2. Configure MCU Core System and APB Bus System, select UART0 or UART1 to generate Gowin\_EMPU\_M3 hardware design with UART function;
3. Instantiate Top Module, import user designs, and connect user designs with Top Module;
4. Or use Gowin\_EMPU\_M3 hardware reference design:  
Gowin\_EMPU\_M3\ref\_design\FPGA\_RefDesign

### 5.1.2 Physical Constraint

Constrain the UART0 and UART1 port in Gowin\_EMPU\_M3 to FPGA IO.

## 5.2 Software Programming

Please refer to [4 Reference Design](#) the software programming reference design of Gowin\_EMPU\_M3 in the software environment of ARM Keil MDK (V5.26 and above) or GOWIN MCU Designer (V1.1 and above).

## 5.3 Board Level Connection

Connect DK-START-GW2A55 V1.3 development board with USB to serial board, then connect USB to serial board with PC.

Take Gowin\_EMPU\_M3 hardware reference design in SDK for an instance, the port constraints of UART0 and UART1 are shown in Table 5-1 .

Table 5-1 UART0/1 Port Constraints in Reference Design

UART	Ports	IO
UART0	RXD	AB2
	TXD	AB1

UART	Ports	IO
UART1	RXD	AB3
	TXD	AA3

## 5.4 Serial Debugging Assistant

Open the serial debugging assistant software, as shown in Figure 5-1 .

1. Refer to the PC device manager to select a proper communication serial port;
2. Refer to the baud rate set in the software programming design to configure the serial port communication baud rate as 115200;
3. The stop bit is set to 1;
4. The data bit is set to 8;
5. No parity;
6. Open the serial port;
7. Development board power-on;
8. The serial port sends and receives debugging information.

**Figure 5-1 Serial Debugging Assistant**



